

MEGAPRO MP-8000NS DIAGRAM

NUMBER PCB	FUNCTION REMOTE
6	
5	3,T-
4	6,PAUSE
3	STOP
2	Kb,T+,9,8
1	K#,RESERVE,0
24	4,1
23	BGV,7,5,2
21	7
20	3,6,Kb
19	STOP,T+,K#,BGV
18	PAUSE
17	
16	4,5
15	T-,9,RESERVE
14	8,0,1,2

The Ultimate Entertainer

